



COMPLI 500

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части -



43137-04

①	Steuerung	Control unit	
	510/4, 515/4		JP45788
	525/2, 525/4		JP45789
	535/2		JP45790
②	DN150 / DN100	DN 150 / DN100	JP48871
③			JP43713
④			JP42798
⑤			JP47287
⑥			JP44860
⑦			
	510/4, 515/4		JP46839
	525/2, 525/4		JP47717
	535/2		JP47303
⑧			JP43712
⑨			JP43710
⑩			JP43709
⑪			
	510/4		JP45778
	515/4		JP45779
	525/4		JP45780
	525/2		JP45781
	535/2		JP45782
⑫			JP43705
⑬			JP43711
⑭			JP43706
⑮			JP47966
⑯			JP43707



① Steuerung	Control unit	
1010/4 BWE		JP47285
1010/4, 1015/4		JP47286
1025/4, 1025/2		JP45786
1035/2		JP45787
② DN 150 / DN 100	DN150 / DN 100	JP48871
③		JP43713
④		JP42798
⑤		JP47287
⑥		JP44861
⑦		JP47304
⑧		
4 m Leitung		JP43712
15 m Leitung		JP48227
⑨		JP43710
⑩		JP43709
⑪		
1010/4 BWE, 4 m		JP46754
1010/4 BWE, 15 m		JP48684
1010/4		JP45778
1015/4		JP45779
1025/4		JP45780
1025/2		JP45781
1035/2		JP45782
⑫		JP43705
⑬		



① Leitung	Cable	
10/4, 15/4, 25/4		JP43717
1010/4 BWE, 4 m		JP43721
1010/4 BWE, 15 m		JP48685
② Stator + Gehäuse	Stator + Housing	
10/4, 15/4, 25/4		JP47042
1010/4 BWE		JP43722
③ Rotorwelle	Rotor shaft	
10/4, 15/4, 25/4		JP45791
1010/4 BWE		JP46801
④ Motorabdichtung	Motor seals	JP46806
⑤ Laufgradbefestigung	Impeller fixation	
10/4, 15/4, 25/4		JP46802
1010/4 BWE		JP46803
⑥ Lagersatz	Bearing set	JP46724
⑦ Lagerschild	Bearing housing	JP43720
⑧ Dichtungssatz	Seal set	JP46807
⑨ Laufgrad	Impeller	
1010/4 BWE		JP47290
10/4		JP45793
15/4		JP45794
25/4		JP45795
⑩ Schraubensatz	Screw set	JP47291

[illegible]